

BOX D

MODELS #838W & 868W– 8 TON JACK

ENCLOSED PER JACK:

- | | |
|--------------------|-------------------------------|
| 1 – Hydraulic Ram | 1 – Jack Handle |
| 1 – Support Collar | 1 – Collar, Safety Locking |
| 7 – Bolts | 1 – 3/8" x 7" Pump Handle Pin |
| 8 – Lock Washers | 3 – 24" Braces |
| 9 – Nuts | 1 – 6" Ram Extension |



Step 1: Mount the hydraulic cylinder to the frame by bolting through the frame into the existing hole in the cylinder bottom. Use a jam nut arrangement and 3/8" x 1" bolt, as shown.

Step 2: Bolt each brace to the frame, and install the left/right wheel mounting brackets at this time, using two 3/8" x 1" bolts to secure the brackets using two of the outer holes.

Step 3: Install the centering collar over the top of the cylinder. Attach the collar to the braces using the jam nut hardware configuration, as shown. Use three 3/8" x 1 1/4" bolts. Finger tight.

Step 4: Center the cylinder in the collar as you would a Christmas tree in its stand. Bring the bolts into firm contact with the cylinder. Do not over tighten

Step 5: Tighten the jam nuts, brace to collar, securing the braces firmly.

Step 6: Tighten the brace to frame bolts and mount the wheels to their respective mounts using the 1/4" x 7/8" bolts and lock nuts.

Step 7: Install the 6" base riser, as needed for higher jack points.

Step 8: Install and secure the 6" top extension as needed for higher jack points.

